

sEMG De-noising and Processing


Miao Wu

2018.8.10


Adviser: Chenglong Fu



Raw sEMG signal



signal of rest state



signal of motion state



Raw sEMG signal

➤ Characteristics

- weak
- instable
- randomness

➤ Noises

- motion artifacts
- 50Hz power-line interference
- 100Hz noise at rest state



Literature review

- Full-wave rectifier
- Low-pass filter
- Inverting amplifier
- Amplifier
- Band-pass filter
- Notch filter
- Wavelet signal denoising



Band-pass filter

➤ 5 Hz high-pass filter to remove motion artifacts

- 吴远皓.自然手势识别方法及可穿戴设备设计[D].北京:清华大学工学硕士学位论文.2017.

➤ 10-500 Hz band-pass filter


- 吴冬梅,张欣,张志成,等.表面肌电信号的分析和特征提取[J].中国组织工程研究与临床康复,2010,14(43):8073-8076.

➤ My plan

- design a band-pass filter function with adjustable passband frequencies
- the sensors would be applied to different body parts with different range of frequencies



Band-pass filter




signal processed by 10-500 Hz band-pass filter



Notch filter


- remove 50 Hz power interference and 100 Hz noise



signal of rest state




Notch filter



```
f0=100;
Q=100;
wo=f0/(Fs/2);
bw=wo/Q;
[b1,a1]=iirnotch(wo,bw);%设计100赫兹陷波滤波器

EMG_filter1=filter(b1,a1,EMG);%100赫兹过滤信号
```



```
f01=50;
Q=35;
wo=f01/(Fs/2);
bw=wo/Q;
[b2,a2]=iirnotch(wo,bw);%设计50赫兹陷波滤波器


EMG_filter3=filter(b2,a2,EMG_filter2);%50赫兹过滤信号
```




Wavelet signal de-noising

➤ Advantages

- combine feature extraction and low-pass filter
- keep characteristics of original signal






Wavelet signal de-noising

```
figure(2)
lev=5;
xd=wden(EMG, 'heursure', 's', 'one', lev, 'sym8'); %启发式SURE阈值选择算法
subplot(3, 1, 1)
plot(xd)
title('One de-noised function')

xd=wden(EMG, 'heursure', 's', 'sln', lev, 'sym8'); %软SURE阈值选择算法
subplot(3, 1, 2)
plot(xd)
title('Sln de-noised function');

xd=wden(EMG, 'sqtwolog', 's', 'sln', lev, 'sym8'); %固定阈值选择算法
subplot(3, 1, 3)
plot(xd)
title('Sqtwolog de-noised function');
```







Real-time data plotting

➤ Revise the plots layout

- compare original signal with filtered signal



original figure



revised figure



Real-time data plotting

- Delete channels without signal input
 - improve speed

```
if counter==1
    for n=1:16
        if data_arrayEMG(n)==0
            %         ch=[ch,n];
            close(figures(n));
            ch(n)=[];%删除第n个通道
        end
    end
    %     setUpPlots();
end%根据第一次读取的data_arrayEMG数据，删除掉不显示数据的通道
```



Future work

- Design EMG filters
 - notch-filter
 - band-pass filter
 - wavelet signal filter
- Realize real-time signal plotting
 - data stream
 - plot
 - speed
- Extract signal features
 - valid signal extraction and assessment

Thanks